



## ERROR 7 INSTRUCTIONS

Loosen the femur adjustment knobs.



Raise the carriage to above zero. This can be done by lifting the unit at the top pivot points or by sliding the black femur bars up the chrome bars.



Re-tighten the femur adjustment knobs. Turn the unit off and back on with the power switch.

